

- Cut out the paper template including the 1.96" and 4.40" holes and tape it to the dash panel top side.
 Fold down the 5 tabs and mark the location of the 5 17/64" holes. Drill the 5 17/64" holes.
 Install the trim rail using the 2 end stanchions, 3 through hole stanchions and #10-32UNF screws.