

GPS SPEEDOMETER INSTALLATION GUIDE

FOR CHROME DASH PANEL ASSEMBLY

1 Add Speedo Seal

Fit the black rubber gasket seal around the inner edge of the speedometer opening on the chrome dash panel.



2 Insert Speedometer

Lower the speedometer gauge directly into the housing from the front side until it rests flush against the seal.



3 Flip Over

Turn the dash panel assembly over carefully to access the rear casing and wiring.



4 Align Speedo Back Clamp

Position the black retaining ring clamp onto the back of the speedometer, aligning its locking tabs with the mounting studs inside the dash panel.



5 Press Down to Clip In

Press firmly down on the tabs until the clamp snaps securely into place over the studs, locking the gauge assembly in position.

