

V-Twin Mfg.
60mm Digital Tachometer
With Black Face
VT Part No. 39-0860

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

Installation Instructions:

1. Connect the black wire on the tachometer to a convenient ground on the engine or battery. A good ground is critical for proper operation of the tachometer.
2. Connect the red wire on the tachometer to a switched 12 volt power source.
3. Connect the green wire on the tachometer to the negative side of the coil, the tachometer lead on the ignition, or to a tachometer adapter depending on your application. The negative side of the coil is the side leading to the ignition module. (On stock bikes this is usually a blue or pink wire.) The positive side of the coil supplies 12 volts from the ignition switch.

NOTE: Some bikes with single-fire ignitions will require a tachometer adapter, available separately.

