

V-Twin Mfg.
Chrome Oil Filter Housing
Fits 1992-99 BT
VT No. 40-9958

This is a custom application rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

This kit fits all 1992 – 1999 1340 Evolution models.

Installation

1. Remove oil filter.
2. Remove oil line compression fittings at oil filter mount and remove oil lines. Cover openings of oil lines to prevent any foreign material from contaminating oil system. If necessary, remove oil line clamp from motor to allow oil lines to be removed.
3. Remove oil filter mount screws and washers and remove oil filter mount. Remove seals from bottom of oil filter mount.

CAUTION: Be sure lines bottom in oil filter mount when inserted. If they are not fully in the bottom of the holes, they will leak oil.

4. Place chrome oil filter mount (1) in position and install oil filter mount screws (4) and washers (5) from kit. Tighten screws to 13-16 ft-lbs.
5. Install compression fitting oil seals (3) from kit in chrome oil filter mount holes.
6. Install compression fittings in oil filter mount. Do not tighten at this time. Install oil filter adapter (2) into mount and tighten snugly.
7. Install oil lines in compression fittings. Be sure the lines bottom in the holes.
8. Tighten oil line compression fittings to 25-35 **in-lbs.** Install oil line clamp, if removed.
9. Install oil filter.

Item	Description
1	Oil filter mount
2	Washers (2)
3	Seal and ferrule (2)
4	Cap screws (2), 5/16-18 x 1-1/4 in. long

