

**V-Twin Mfg.
Chrome Rocker Box Dress Cover Kit
Fits 1986 and up XL Models
VT No. 42-0796 and 42-0947**

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

Installation Instructions:

1. Remove the fuel tank as per the instructions listed in the service manual.
2. On 2004 and up models, install the new Dress Covers using the provided bolts and flat washers. Place the fiber washers over the OEM covers. Place a 5/16 flat washer (not included) over the fiber washer. (see figure 1) Place the Dress Covers over the 5/16 flat washers (see figure 2) and torque the supplied flat washer and bolts in accordance to the service manual specifications.
3. On 1986 – 2003 models install the new Dress Covers using the provided bolts and washers. Be certain to use the fiber washers under the Dress Covers. Place the Dress Covers over (see figure 2) the fiber washers and torque the bolts with the supplied flat washer and bolts in accordance to the service manual specifications.
4. Replace the fuel tank as per the instructions listed in the service manual.



Figure 1



Figure 2



Figure 3



Figure 4