

**V-Twin Mfg.
Chrome Dress Up Kit
For Use on 1991 - 2003 and up XL Models
VT No. 42-1050**

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

Installation Instructions:

1. Remove Only the bolts shown in these instructions. (See photos below)
2. Install the new dress up covers using the provided bolts. Be certain to use the bolts of proper length.
3. On the left side, the shifter linkage will need to be removed. Refer to the service manual for instructions. Some derby covers with raised features will not fit under the dress up cover and will need to be replaced.
4. Install the belt cover using the hardware provided.

