

V-Twin Mfg.  
Rear Axle Covers Chrome Skull Design  
Fits 1986-1999 FLST, FXST  
VT #44-0812

**Instructions:**

1. Raise bike up so the rear wheel is off the ground.

[Proper support of the bike is required. Support the rear wheel.]

2. Remove the axle nut and remove the axle from the wheel.
3. Remove cover mounting bracket from cover by loosening and removing the 3 allen screws.
4. Position the mounting bracket on the axle and install the axle back through the wheel.
5. Install the second cover mounting bracket and axle nut.

[Torque axle nut to service manual specifications.]

6. Install chrome cover with the 3 allen screws.

**NOTE:** Loctite is recommended.