

## **DRIVER BACKREST PAD**

### **VT No. 47-0004**

Separate purchase and installation of additional parts or accessories may be required for proper installation of this kit on your model motorcycle.

#### **INSTALLATION**

1. Install appropriate mounting bracket hardware (sold separately).
2. Hold slit between rider and passenger seat open. On rider backrest, compress backrest rods and spring. Insert rods into backrest mounting bracket.

#### **BACKREST PAD ADJUSTMENT**

1. Adjust fore/aft position of backrest pad. Use 3/16 inch hex wrench to adjust set screw that is accessible through eyelet opening on rear of pad. If possible, do not remove set screw because it is difficult to install.