

**V-Twin MFG.
SISSY BAR SIDE STRAP
Fits 2006-UP DYNA Models
VT No. 50-0858**

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

Installation Instructions: It is recommended to install one side at a time for proper support of the fender. Caution should be taken to protect the paint surface. Use Loctite on all hardware.



1. Remove the OEM reflector.



2. Remove the OEM turn signal assembly by removing bolt from under the fender



3. Remove the front fender strut bolt.



4. Align the side plated slot over the turn signal wire and re install the bolts in the turn signal assembly and front fender strut.



5. Re install the turn signal and fender hardware.



6. Install the reflector, using the provided tape.