

V-Twin Mfg.
Rear Fender Top Trim Set Stainless Steel
VT Part No. 50-1045

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

VT No. 50-1045
HOLE TEMPLATE FOR MOUNTING TRIM
STRIPS TO REAR FENDER

CENTER THE PAPER FROM LEFT TO RIGHT,
MEASURE 7 INCHES FROM THE CENTER OF
THE HINGE TO THE LINE AS SHOWN,
TAPE THE PAPER TO THE FENDER,
CENTER PUNCH THE 16 HOLE LOCATIONS,
REMOVE THE PAPER, AND DRILL THE HOLES
WITH A 7/32 DRILL.

Rear

MEASURE 7 INCHES FROM THE
CENTER OF THE HINGE TO
THIS LINE.



CENTER LINE

FRONT

USE A 7/32 DRILL
FOR ALL 16 HOLES

