

FENDER TRIM RAIL KIT
VT 50-1532
INSTALLATION INSTRUCTIONS

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

1. Measure the distance between the 6.00" lines on the template shown below to determine if any scaling has been done by electronic transfer or printing. If the lines are not 6.00" apart, the template can not be used.
2. Cut out the paper template and center it on the front fender at the high point of the fender curve or other desired location.
3. Tape the template to the fender.
4. Mark the location of the holes and remove the template.
5. Drill (4) 11/32" holes.
6. Install the trim rail stanchions and rails using the hardware provided.

