

**V-Twin Mfg.
Right Side Tool Box Kit
Fits 2006-UP FXD,FXDWG
VT No. 50-2025**

Use w/Peg Relocation Brackets 27-0861

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

Installation Instructions:

1. Remove rubber plugs from the right forward end of the swing arm and discard.
2. Install the bracket on the swing arm using the 3/8-16 x 1" bolt with lock washer as shown in illustration below.
3. Install the tool box on the bracket using the three 5/16 -18 X 3/4 flat head tapered allen bolts and conical washers as shown in illustration below.
4. If mounting with rear foot peg mounts VT No. 27-0861, remove the 1" long bracket screws and install the right foot peg mount on top of tool box bracket with the 1.25" hex bolts and lock washers as shown in illustration below.
5. Install the matching left foot peg with the 1" hex bolts and lock washer.

Parts List

QTY	Description	V-Twin No.
1	Tool box	50-0600
1	Bracket	31-1752
2	3/8" -16 x 1 Hex bolt	100-041
3	5/16" -18 x 3/4 Flathead tapered allen bolt	500-079
3	5/16" Conical washer	37-9178
2	3/8" Split lock washers	400-001
2	3/8-16 x 1.25" Hex bolt	100-027

