## Disassembling Process

Step 1



Step 3



Step 5



Step 2



Step 4



Step 6



Step 7



Step 8



Step 9 Keep these original parts to re-assembling



## Replacement parts



total parts need to assembly



## Assembling Process;

Step 1



Step 4



Step 2



Step 5



Step 6



Step 8



Step 10



Step 7 Adjust this nut to control the space and put the pin



Step 9



Step 11



Step 12



Step 14



Step 13

