V-Twin Mfg. Chrome 4-3/4" Riser Set VT Part No. 26-0941

This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.

This handlebar riser kit fits 1997 and later FXST/I/C and FXDL/I models.

Installation Instructions:

- 1. Cover the front of the fuel tank and instrument console.
- 2. For FXST/I/C: Cut the cable straps around the risers.
- 3. Supporting the handlebars, remove the 4 socket head cap screws and the upper handlebar clamp(s) and gently rest the handlebar assembly on the covering.
- 4. Remove the hex head bolts under the upper triple clamp and the risers.
- Remove the lower cup washers, rubber bushings, spacers, upper rubber bushings and upper cup washers and discard. Allow the ground wire and eyelet to hang.
- 6. Install the spacers (1) between the upper and lower rubber bushings (2) in the triple clamp. Install cup washers (3) on top bushings.
- 7. Right Side: Install a hex head bolt (4) through the internal tooth lock washer (5), the ground wire eyelet, a lock washer (6) and a cup washer into the triple clamp.
- 8. Left Side: Install a hex head bolt through a lock washer, a cup washer and into the tripe clamp.
- 9. Fit the large flat washers (7) over the bolts.
 - a. For FXDL/I: Slip 2 flat washers over each bolt.
 - b. For FXST/I/C: Slip 1 flat washer over each bolt.
- 10. Install the risers (8) and hand tighten the bolts to hold the risers in place.
- 11. Center the handlebar knurling between the upper clamp (9) and the risers. Position handlebars and tighten the cap screws (10) until the gap between the clamp and risers are equal front and rear. Tighten to 12-15 ft-lbs.
- 12. Tighten the 2 riser bolts to 30-40 ft-lbs.
- 13. For FXST/I/C: Install the 2 cable straps (not included) around the risers and control wires.
- 14. Rotate handlebars from full lock to full lock to verify clearance and cable operation.

Parts List

Item Description (Quantity)

- 1. Spacer (2)
- 2. Rubber bushings (4)
- 3. Cup washer (4)
- 4. Hex head bolts (2)
- 5. Internal tooth lockwasher
- 6. Lockwasher (2)
- 7. Flat washer (4)
- 8. Riser (2)
- 9. Upper clamp
- 10. Socket head cap screw (4)

