

32-0976 KIT LIST					
VT#	QTY	OEM#	DESCRIPTION	YEARS	INDEX #
12-1110	1	255	ROLL PIN (MUST BE CUT TO LENGTH AFTER INSTALL)	1958-69	1
12-0144	1	612	ADAPTER PLATE ROLL PIN	1967-69	4
32-1027	1	1074W	ADJUSTMENT SCREW	1965-67	6
37-1030	1	29601-48	SCREW (PAIR)	1958-E62	8
37-1050	1	1867	ADAPTER PLATE SCREW (PAIR)	L1962-69	8
100-014	2	4410	BOLT 1/4-28X3/4 HEX HEAD	1958-69	9
37-1024	1	7683	NUT FLEXLOC (2 PC USED)	1958-69	15
14-0501	1	11101	O-RING (1 PC USED)	1965-68	18
14-0107	1	12023	OIL SEAL (1 PC USED)	1968-69	20
13-0157	1	27291-32	WIRE BLOCK SPRING (1 PC USED)	1965-69	21
35-0207	1	27450-36	WIRE BLOCK KIT	1965-69	22
37-1025	1	29531-55	COVER SCREW (4 PC USED)	1958-69	25
15-0149	1	29550-55	GASKET (1 PC USED)	1958-69	28
13-9208	1	29560-55	COIL SPRING (2 PC USED)	1958-69	29
14-0090	1	-	BEARING SEAL FOR POINT PLATE	1958-69	-
32-1058	1	-	RACE FOR POINT PLATE BEARING	1958-69	-
37-1026	1	29564-55A	WASHER W/ NOTCH (PAIR)	1958-69	34
37-1027	1	29565-55	CONTACT SCREW WASHER	1958-69	35
14-0528	1	29603-48	SEAL (1 PC USED)	1958-65	42
37-1031	1	29607-62	ADAPTER WASHER (2 PC USED)	1962-64	44
31-1033	1	29620-55	CLIP POINTS PIVOT STUD	1958-69	46
12-1113	1	29621-55	SNAP RING HOUSING BEARING	1958-69	47
31-1034	1	29622-55A	CLIP	1958-69	48
37-1032	1	29624-55	WASHER W/ NOTCH	1958-69	50
32-0036	1	29628-55	WICK HOLDER	1958-69	54
14-0166	1	29630-55	SEAL	1958-69	55
37-1033	1	29632-55	SCREW W/ WASHER	1958-69	56
37-1049	1	29637-55	DRIVE HOUSING SCREW (4 PC USED)	1958-E62	57
37-1041	1	29632-62	DRIVE HOUSING SCREW (SET OF 4)	L1962-E66	57
37-1034	1	29632-66	DRIVE HOUSING SCREW (4 PC USED)	L1966-69	57
37-1036	1	29633-62	SCREW W/ WASHER (2 PC USED)	1958-69	58
37-1037	1	29634-55	SCREW W/ WASHER	1958-69	59
37-1038	1	29635-55	BREAKER ARM WASHER	1958-69	60
37-1040	1	29638-55	SCREW (PAIR)	1958-64	62
37-1042	1	29638-55	SCREW (SET OF 4)	1958-64	64
32-1002	1	26939-55	VENT COVER	1958-69	65
37-1043	1	29640-55	SCREW WITH WASHER	1958-69	66
32-1018	1	26941-55	SCREEN	1958-69	67
15-0154	1	32522-37	GASKET (1 PC USED)	1958-69	81
10-0717	1	32525-36A	BUSHING (1 PC USED)	1958-69	82
13-0168	1	64409-47	ADJUSTMENT SCREW SPRING	1965-67	85

BEARING RACE AND SEAL SAMPLE IN KIT HAS NO OEM NUMBER.

NOTE: #34 WASHER IS SAME THICKNESS AS #50 WASHER AND MADE WITH NOTCH.

THE MAGNETO IS MOUNTED IN TWO WAYS:

1) ON THE 1964 AND EARLIER MODELS THE MAGNETO IS MOUNTED IN A FIXED POSITION TO PRODUCE ADVANCED SPARK TIMING ONLY.

2) ON 1965-1969 MODELS A MOVABLE MOUNTING PLATE ALLOWS THE MAGNETO TO BE TURNED TO A RETARDED TIMING POSITION FOR STARTING ENGINE. MAGNETO IS ADVANCED AND RETARDED MANUALLY BY TURNING THE LEFT HANDLEBAR GRIP.

