

Tool Index 2010

A	
ADVERTISING.....	1217
AIR BLASTER.....	1235
AIR FILTER	
Oil/Cleaner.....	1230
ALLEN SCREW LIST.....	1277
ALTERNATOR.....	1252
Ring Replacement.....	1222
AXLE.....	1261,1262
B	
BATTERY.....	1252
BEARING.....	1253-1255
BELT.....	1256
BOLT LIST.....	1277
BOOKS.....	1226-1229
BRAKE.....	1259
Caliper Piston.....	1259
Disc/Rotor Lock.....	1218
Fluid.....	1231
BREATHER	
Valve Service.....	1224
BUNGEE CORD.....	1218
BUSHING.....	1253
BUSHING LIST.....	1264
C	
CABLE OILER.....	1230,1261
CABLE RACK.....	1216
CAM.....	1240-1243
Bushing Replace.....	1221
Tune A Cam.....	1243
CAPS(Chrome).....	1275
CARBURETOR.....	1245
CASE	
Bearing Conversion.....	1236
Boring.....	1246
Lapping.....	1239
CATALOG & RACK.....	1217
CHAIN & LUBE.....	1230,1256
CHARGER.....	1252
CHOPPER (MINI).....	1216
CHROME CAPS.....	1275
CLEANER/POLISH.....	1230
CLUTCH.....	1257
COLLECTIBLES	
Cast Iron Toy.....	1216
Poster.....	1216
Scale Models.....	1216
Sky King Trike.....	1216
CONNECTING ROD.....	1237
COTTER PIN LIST.....	1273
COUNTER SHAFT.....	1254
COVERS(Motorcycle).....	1219
CRANKCASE.....	1246,1252
CRANKSHAFT.....	1238-1239,1243
Balance Service.....	1223
CYLINDER.....	1246-1247
Boring Service.....	1220
Sleeving.....	1220
D	
DEALER PROMOTION	
Banner.....	1217
Bank.....	1216
CD Catalog.....	1217
Cable Rack.....	1216
Catalog.....	1217
Catalog Rack.....	1217
Counter Mat.....	1217
Dealer Decals.....	1217
Labels.....	1217
Mat.....	1217
Poster.....	1216
Shop Bag.....	1217
Sign/Postcard.....	1217
V-Twin Promo.....	1217
Wire Tag.....	1217
DEUTSCH.....	1251
DIAGNOSTIC.....	1250
DISPLAY STAND.....	1219
DOWEL PIN LIST.....	1273
E	
EFI.....	1245,1250
ELECTRICAL.....	1251,1253
EXHAUST	
Coating.....	1232
Sensor.....	1262

EXHAUST CONTINUED	
Port Replacement.....	1224
F	
FLYWHEEL.....	1236,1240
Balancing.....	1223
Locking.....	1250
Remanufacture.....	1222
FORK.....	1258
Neck Bearing.....	1258
Leg Bushing.....	1224
Oil.....	1231
Seal Driver.....	1258
Spring Fork Rebuild.....	1224
FUEL	
Line.....	1245
Pressure.....	1245
Pump.....	1237
G	
GAS TANK	
Line.....	1245
Sealant.....	1232
Shut Off.....	1244
GASKET LIST.....	1265-1270
Locater.....	1244
Removal.....	1253
Sealant.....	1232
GEAR OIL.....	1231
GENERATOR	
Gear Puller.....	1244
Rebuild Service.....	1225
GOGGLES.....	1218
GREASE.....	1261
H	
HEADS.....	
Remanufacture.....	1221
Resurfacing.....	1221
HELICOIL.....	1263
Installation Service.....	1221
HELMET NET/LOCK.....	1218
HOSE	
Clamp/Cutter.....	1245
I	
IGNITION	
Switch.....	1251
Timing.....	1250
IMPACT DRIVER.....	1253,1262
INSPECTION TAG.....	1216
INTAKE WRENCH.....	1262
J	
JETS.....	1245
K	
KEYS.....	1274
KROMMETTS.....	1276
L	
LAPPING.....	1239
LEAN RITE.....	1233
LIFTER.....	1244
LIFTS	
Table.....	1233
Trans/Motor.....	1233,1234
V-Lift.....	1235
LOCK TAB LIST.....	1274
LOCKS.....	1218
LONG BLOCK SERVICE.....	1222
LUBRICATION	
Air Cleaner.....	1230
Bearing Packer.....	1261
Brake.....	1231
Cable/Oiler.....	1230,1261
Chain.....	1230
Gear.....	1231
Grease Fitting/Gun.....	1261
Motor/Fork/Trans.....	1231
Tire Seal.....	1230
M	
MAINSHAFT.....	1255
MANUALS.....	1226-1229
MASTER CYLINDER.....	1259

MOTOR SHOP SERVICE	
Alternator Ring Replacement.....	1222
Breather Valve Machining.....	1224
Cam Bushing XL.....	1221
Cam Cover Bushing BT.....	1221
Case Boring.....	1223
Crankshaft Balance.....	1223
Cylinder Boring.....	1220
Cylinder Sleeving.....	1220
Engine Remanufacture.....	1222
Exhaust Port Replacement.....	1224
Flywheel Balancing.....	1223
Flywheel Remanufacture.....	1222
Fork Leg Bushing Install.....	1224
4/5 Speed Rebuild Service.....	1224
Generator Rebuild.....	1225
Head Remanufacturing.....	1221
Head Resurfacing.....	1221
Long Block Remanufacture.....	1222
Short Block Remanufacture.....	1222
Spark Plug Helicoil Install.....	1221
Spring Fork Rebuild.....	1224
Transmission Remanufacture.....	1224
Valve Seat Service.....	1220-1221
Wheel Truing/Building.....	1224
MOTOR STAND.....	1234
MOTORCYCLE COVER.....	1219
N	
NUT LIST.....	1279-1280
O	
O RING LIST.....	
1271	
OIL	
Drain Reserve.....	1231
Filter Wrench.....	1231
Line.....	1245
Motor/Trans/Gear.....	1231
Pressure.....	1237
Primary/Fork.....	1231
Pump.....	1237
P	
PAINT.....	1230
PARTS MANUAL.....	1226-1229
PIN LIST.....	1273
PINION.....	1239,1242
PISTON.....	1237
Ring.....	1237
PLUGS(Timing).....	1250
POLISH/CLEANER.....	1230
Points.....	1230
POSTER.....	1216
PRIMARY.....	1256
Oil.....	1231
PROMO.....	1216-1217
PULLERS(Bushing/Race).....	1253
PUNCH.....	1253
PUSHROD.....	1244
R	
RACE.....	1237,1253
RATCHET PLATE RIVET.....	1257
RIVET.....	1253,1273,1278
ROCKER ARM.....	1247
ROD.....	1237
Lapping.....	1239
ROLL PIN.....	1273
ROTOR(Brake).....	1259
S	
SCREW LIST.....	1280
SEAL LIST.....	1272-1273
SEALANT	
Gasket.....	1232
Thread/Lock/Repair.....	1232
Crankcase/Cam.....	1232
Hi Temp.....	1232
Tank.....	1232
Tire.....	1230
SECURITY.....	1218
SERVICE MANUAL.....	1226-1229
SHIFT	
Fork Gauge.....	1254
Pawl.....	1255
Shaft.....	1255
SHIM LIST.....	1264
SHOCK.....	1259
SHOP SERVICES.....	1220-1223

SHORT BLOCK SERVICE.....		1222
SNAP CAPS.....		1275
SPACER LIST.....		1278
SPARK PLUG		
Helicoil Replace.....		1263
Plug/Tap.....		1263
Test/Firing/Index.....		1250
Repair Kit.....		1263
Thread Chaser.....		1263
SPRING FORK REBUILD.....		1224
SPOTLAMP.....		1262
SPROCKET		
Nut.....		1254
SPROCKETSHAFT.....		1238,1240
Degree Wheel.....		1243
STANDS(CENTER).....		1219
STARTER BEARING.....		1256
STUD LIST.....		1274
Installer.....		1274
SUSPENSION.....		1259
SWING ARM.....		1259,1261
T		
TAP & DIES.....		1263
TAPPET(Oil Screen).....		1244
THREADING.....		1263
TIE DOWN.....		1233
TIMING.....		1250
TIRE		
Changer.....		1260
Repair.....		1260
Sealer.....		1230
TOOL ROLL.....		1218,1225
TOOL KITS.....		1225
TRANSMISSION.....		1254-1255
4/5 Speed Rebuild.....		1224
Oil.....		1227
Stand.....		1234
TRUING STAND.....		1260
TWIN CAM		
Cam Clearance.....		1241
Cam Shaft.....		1243
Case Bearing Conversion.....		1236
Cylinder.....		1246
Lapping.....		1239
Pinion.....		1239
Rod.....		1239
Sprocket Shaft.....		1240
Transmission.....		1255
Wrenches.....		1262
Wrist Pin.....		1239
V		
V-ROD.....		1257
V-TWIN PROMO.....		1216-1217
VALVE.....		1244,1247-1249
Compression Release.....		1247
Cover Wrench.....		1244
Guide.....		1249
Lifter.....		1244
Seat Service.....		1220-1221
VISE JAW PADS.....		1253
VOLT METER.....		1252
W		
WASHER LIST.....		1278,1280
WHEEL		
Bearing Greaser.....		1253
Building & Truing.....		1224
Chock.....		1235
Compensator Bearing.....		1253
Race/Driver.....		1253
Truing Stand.....		1260
WIRING.....		1251,1253
WRENCHES.....		1254,1262
WRIST PIN.....		1237