



# Bushings

<b>10-0719</b>	—	54-79 XL Kick Starter Shaft w/Seal
<b>10-2493</b>	33101-32	Kick Starter Shaft 45 Side Valve
<b>10-2494</b>	33213-30	Kicker Pedal All Twins
<b>10-0720</b>	33288-37	41-69 BT Kick Start Shaft with Seal
<b>10-0721</b>	33438-50	50-85 BT Mainshaft Starter Gear 4-Speed w/Stock Gear
<b>10-2486</b>	—	As above .005 O/S for Aftrmrkt Gear
<b>10-0722</b>	33442-57A	57-72 XL Starter Ratchet Gear
<b>10-0723</b>	33442-73	73-79 XL Starter Ratchet Gear
<b>10-8527</b>	33445-89	89-93 BT Prim Housing Starter Shaft
<b>10-8528</b>	33446-89	89-93 BT Prim Housing Starter Shaft
<b>10-2502</b>	33638-52	52-69 FL-FLH Foot Shift Bracket
<b>10-2511</b>	33638-70	70-85 FL-FLH All FXWG-FXST Foot Shift Bracket
<b>10-8529</b>	33713-85	87-up FLT Prim Housing Shifter Shaft
<b>10-0724</b>	34037-52	54-74 XL Shifter Shaft Shifter
<b>10-2483</b>	34037-75	77-81 XL Shift Pedal Shaft
<b>10-2518</b>	34427-38	(Small) Shifter Shaft 45 Side Valve
<b>10-0732</b>	34430-36	37-76 BT Hand Shift Shifter Shaft
<b>10-2514</b>	34432-38	(Large) Shifter Shaft 45 Side Valve
<b>10-0725</b>	34435-52	41-79 Big Twin Shifter Shaft
<b>10-0726</b>	34498-52	52-79 Big Twin Pawl Carrier
<b>10-2488</b>	34632-84B	84-up FXR All Shifter Shaft
<b>10-0748</b>	34898-79	78 only, All XL Brake Pivot Shaft
<b>10-0727</b>	35094-65	65-85 4-Spd BT Mainshaft Drive Gear
<b>10-2487</b>	—	As above for Andrews Gear only
<b>10-2515</b>	35316-41	Low Gear 45 Side Valve
<b>10-2517</b>	35320-41	Second Gear 45 Side Valve
<b>10-0728</b>	35322-38	38-58 BT Mainshaft Third Gear
<b>10-2516</b>	35787-52	54-72 All XL's Countershaft 1st Gear
<b>10-0752</b>	35787-72	73-84 XL Countershaft 1st Gear
<b>10-0729</b>	35789-36	41-85 BT 4-Spd Cntrshft Low Gear
<b>10-0730</b>	35791-36	41-85 BT 4-Spd Cntrshft 2nd Gear
<b>10-2547</b>	36035-26	29-73 45" Countershaft Left
<b>10-2490</b>	36042-41	41-73 45" Countershaft Side Cover
<b>17-9830</b>	37436-36	36-84 Big Twin 4-Speed Mainshaft Clutch Pushrod, 5 pk
<b>10-0753</b>	37458 41	Clutch Gear 45 Side Valve
<b>10-0751</b>	37458-52	52-85 All XL Models Clutch Gear
<b>10-0733</b>	40520-63	77-up XL Shifter Shaft In Right Crankcase 66-up XL Shifter Shaft In Chain Cover
<b>10-0740</b>	41685-37	37-57 BT Brake Backing Plate Cam
<b>10-2496</b>	—	Same as above .015 O/S
<b>10-1256</b>	42443-80	80-up XL Brake Pedal All
<b>10-2497</b>	47094-58	58-84 BT Seat Post
<b>8859-1</b>	47581-29	29-73 45's Seat Post
<b>7708-1</b>	47583-36	36-57 BT Seat Post
<b>10-0741</b>	47755-31	37-57 BT Brake Crossover Shaft
<b>10-2505</b>	47757-52	75-78 XL Shifter Cross Shaft
		52-78 XL Brake Cross Shaft
<b>10-2500</b>	51925-37	37-64 BT Seat Tee
<b>10-2501</b>	51925-65	65-80 BT Seat Tee
<b>10-0743</b>	60593-74	74-85 FX 4-Spd Inner Primary Shifter
<b>10-2489</b>	60629-82	82-83 Shifter Shaft

VT No.	OEM	Item
<b>10-2498</b>	413-30	30-36 74" 80" Right Case
<b>10 2519</b>	416-30	30-36 74" 80" Left Case
<b>10-8524</b>	662-29	30-36 BT & 45 Timer Shaft
<b>10-8525</b>	662-30	30-36 BT & 45 Cam Gear Shaft
<b>10-8526</b>	662-34VL	34-36 BT & 45 Oiler Drive Shaft
<b>10-0700</b>	17428-57	66-up BT 57-up XL Rocker Arm 10 pk
<b>10-0760</b>	24331-36	57-up XL 29-73 45" Std Pstn Pin, pr
<b>10-0761</b>	—	As above .002 O/S
<b>10-0762</b>	—	As above .005 O/S
<b>10-0763</b>	24332-36	As above .010 O/S
<b>10-0756</b>	24334-36	36-99 BT Std Piston Pin, pr
<b>10-0757</b>	—	As above .002 O/S
<b>10-0758</b>	—	As above .005 O/S
<b>10-0759</b>	24335-36	As above .010 O/S
<b>10-0703</b>	24641-36	36-99 BT Oil Pump Shaft
<b>10-0704</b>	25581-36	41-69 BT Crnkse Cover Gear Std
<b>10-2524</b>	—	Same as above .005 O/S
<b>10-0705</b>	25581-70	70-99 BT Crnkse Cover Gear Std
<b>10-2525</b>	—	Same as above .005 O/S
<b>10-0706</b>	25582-36	41-54 BT Cover Pinion Shaft Std
<b>10-2526</b>	—	Same as above .005 O/S
<b>10-0707</b>	25582-54	54-72 BT Gear Cvr Pinion Shft Std
<b>10-0708</b>	25582-73	73-92 BT Gear Cover Pinion Shaft
<b>10-2529</b>	—	As above .005 O/S
<b>10-8536</b>	25582-93	93-up BT Gear Cvr Pinion Shaft Std
<b>10-8556</b>	—	As above .005 O/S
<b>10-0709</b>	25586-37	57-up XL Cam Gear #1, 3, 4 Cams Cam Cover Front In L Ex Cam 74/80 Side Valve, Front Ex Cam 45
<b>10-2540</b>	—	As above, .005 O/S
<b>10-0731</b>	25588-37	45" 74" 80" Cam Cvr R. In Cam SV
<b>10-0710</b>	25588-57	57-90 XL Cam Gear #2 Cam Std
<b>10-2541</b>	—	As above .005 O/S
<b>10-0711</b>	—	57-90 XL Gear Kit #1-2-3-4 Std
<b>10-8538</b>	25588-91	91-up XL Gear #2 Cam Std
<b>10-2507</b>	25590-37	45" 74" 80" Cam Cover Rear EX Cam
<b>10-2512</b>	25591-37	74" 80" Pinion Shaft Side Valve Std
<b>10-2503</b>	25593-37	Pinion Shaft 45 Side Valve Std
<b>10-2543</b>	—	As above .005 O/S
<b>10-0712</b>	25593-57	57-76 XL Cam Cover Pinion Std
<b>10-2544</b>	—	As above .005 O/S
<b>10-0713</b>	25593-74	77-up XL Cover Pinion Std
<b>10-2545</b>	—	As above .005 O/S
<b>10-8268</b>	25594-75	77-81 XL Brk Pedal Operating Shaft
<b>10-2506</b>	25595-37	Cover Front In Cam 45 Side Valve
<b>10-8271</b>	25595-52	52-56 K Exhaust Cam
<b>10-0714</b>	25597-36	36-54 BT Crankcase Cam Gear Std
<b>10-2527</b>	—	As above .005 O/S
<b>10-0715</b>	25597-57	57-E84 XL Idler Gear Std
<b>10-2546</b>	—	As above .005 O/S
<b>10-2552</b>	25598-91	1991-up XL Inner Cam
<b>10-2504</b>	25599-37	74" 80" SideValve Crnkcs Cam Shaft
<b>10-2495</b>	25601-37A	45 Side Valve Crnkcs Cam Shft Bush
<b>10-0716</b>	25785-30A	41-69 BT Idler & Circuit Breaker Gear
<b>10-0749</b>	26431-76	77-90 XL Oil Pump Cover
<b>10-0750</b>	26489-75	77-90 XL Oil Pump Body
<b>10-0742</b>	27290-24	Linkert Throttle Shaft, pr
<b>10-0717</b>	32525-36A	36-39 BT Circuit Breaker Housing
		56-69 XL Magneto Housing
<b>10-0718</b>	33099-52A	54-79 XL Kick Starter Shaft