



Primary



Outer Primary Cover Starter Bearing Removal Tool removes 9063 Torrington Needle Bearing for Big Twin and XL covers.
VT No. 16-0717
Note: This tool will also remove the 35961-52 Bearing in Countershaft Gear (Late) 4 Speed Big Twin, and also the 4-Speed Sportster Clutch Gear.



Big Twin Primary Drive Locking Tool is used as a wedge type device to hold the primary drive gear while the proper torque is applied without damaging the primary gear. Constructed of nylon, OEM# 41214.
VT No. 16-0650




Ratchet Plate Riveting Fixture securely aligns plate to drum while setting rivets on 1971-79 XL model clutch drum.
VT No. 16-0165



Starter Jackshaft Seal Installer Tool will easily allow alignment and installation of starter jackshaft seal (OEM#12066) without distortion or damage to seal. For 1994-06 Big Twins except 2006 Dyna.
VT No. 16-1373



Inner Primary Cover Bearing & Seal Remover Installer Tool safely removes and installs inner primary bearing (OEM# 9135) without damage to the new bearing by pushing on the outer perimeter of the bearing. Removes and installs inner primary and seal that the transmission mainshaft passes through (OEM#12052A). For L1984-06 FXST/FLST; 85-06 FLT/FLHT/FXR/FXD/FXDWG
VT No. 16-1367



Primary Locking Bars use to lock primary for servicing.
VT No. Use
16-0680 4-Speed BT's & 5-Speed FXST
16-0681 5-Speed FXR-FLT
16-0682 1991-up Sportster & Buell®
16-1357 2007-up Dyna
16-0327 2007-up FLT



Clutch Adjusting Gauges are used to find the correct distance between the outer drive plate and outer releasing disc for 1971-83 Sportsters, 1936-67 early and 1968-84 late Big Twins. Set of 3 tools
VT No. 16-1807



1971-85 XL Clutch Adjust Tool.
VT No. 16-0123



Primary Drive Aligning Fixture will align teeth on clutch shell with motor sprocket. Fits Ev.
VT No. 16-0203



Primary Plug Wrenches for Sportster models.
VT No. OEM Years
16-0158 1971-84
16-0985* 33186 1971-up
8862-1 Evo 1986-up
***Note:** Uses 3/8 socket handle



Starter Pinion Gear Holder Tool fits 9 and 10 tooth gears.
VT No. 16-0484



Starter Ring Gear Rivet Fixture removes the starter ring gear rivets from Big Twin clutch shells. For 2006-07 BT except Dyna.
VT No. 16-1368

Belt



Final Drive Tool fits final drive pulley, so the nut can be properly set to torque specifications.
VT No. Type
16-0649 BT
16-0588 XL
16-0590 XL (Jims)



Belt Tension Gauge designed to aid in properly adjusting belt tension on models with a secondary drive belt.
VT No. 16-1765



Calibrated Belt Tension Gauge. Accurately measures belt tension.
VT No. 16-0589

Chain



Standard Chain Puller eliminates the annoyances of installing the master link in rear chain. Conveniently pulls chain halves together without loosening at rear wheel. Fits all sizes.
VT No. 16-0611



Chain Puller Tool.
VT No. 16-1615



Link Press Tool presses the side plates on all 530 O-Ring Chains.
VT No. 16-1729

Chain Riveting Tool and Chain Breaker.
VT No. Item
16-1740 Breaker
16-1741 Riveting Tool Set
16-0201 Riveting Tool Set (V-Twin)

Diamond Chain Breaker is excellent for cutting 530 heavy chain.
VT No. Item
16-0255 Breaker Complete
16-0950 Replacement Tip



Small Chain Breaker replaces 12039X.
VT No. 16-0144