





# Battery Side Covers



VT No. 42-0714



## Chrome Battery Side Cover.

VT No.	Fits	Type
<b>1965-84 FLH</b>		
42-0010	1965-69 FL-FLH	Ribbed
42-0508	1970-84 FL-FLH	Ribbed
42-0499	1970-84 FL-FLH	Smooth
42-0507	1970-84 FL-FLH	Louvered
<b>1973-85 FXE-FXEF-FXS-FXB-FXWG</b>		
42-0502		Square View Holes
42-0501		Single Slot View Hole
42-0500		Louvered
42-0097		Louvered w/Square View Hole
42-0714		Embossed
<b>1970-84 FX Kick Start Only</b>		
42-0505		Single Slot View Hole
42-0003		Louvered




## Replacement Battery Straps

VT No.	Application
28-2217	1984-up FXST, FLST, 1980-up FLT, FLTC
42-0517	1970-85 FL, FLH
42-0515	1971-80 FX, Kick only
42-0524	1973-85 FXE, FXWG, FXSB, FXEF
42-0516	1965-69 FL, FLH

**Chrome Battery Cover Kit** includes both top and side covers with correct stainless steel strap. Note style of side cover.

VT No.	Year	Model	Style
42-0542	1970-78	FX	Slotted
42-0543	1973-84	FXE-FXS	Square
42-0546	1970-84	FLH	Ribbed
42-0544	1965-69	FLH	Ribbed

# Top Covers



**Battery Top Cover & Strap Kit.** Save time by ordering the proper cover and hold down strap, display packaged.

VT No.	Application
42-5515	1970-78 FX, Kick only
42-5516	1965-69 FLH
42-5517	1970-84 FLH
42-5518	1973-84 FXE Electric Start

## Chrome Battery Top Covers.

VT No.	Fits
42-0510	1965-84 FLH
42-0512	1971-84 FX
42-0511	1973-84 FXE