




1. Shifter Lever Screw (3)
 VT No: 21-1987 OEM: 1767W
 2: Shifter Lever
 VT No: 21-0215 OEM: 34447-52
 3. Dust Shield
 VT No: 21-0206 OEM: 34555-52
 4. Shifter Cover Screw (4)
 VT No: 17-0074 OEM: 1772W
 5. Shifter Cover Screw (short)
 10-24 x 1-5/32
 OEM: 1764W
 6. Cover Screw Nut
 10-24 x 1/8 x 3/8 hex
 OEM: 7620W
 7. Pawl Carrier Cover
 VT no: 17-0103 OEM: 34551-52
 8. Cover Gasket
 VT no: 15-0519 OEM: 34552-52
 9. Pawl Carrier
 VT No: 17-0071 OEM: 34488-52B
 10. Pawl (2)
 VT no: 17-0068 OEM: 34478-75
 12. Pawl Spring (2)
 VT no: 13-0133 OEM: 34482-53
 13. Pawl Carrier Spring (2)
 VT No. 13-1955 OEM: 34500-52A
 14. Adapter Plate Bracket Screw
 VT No. 37-0077 OEM: 1369
 15. Adapter Plate Screw Washer
 VT No. 37-0346 OEM: 7124
 16. Adapter Plate
 VT No: 17-9895 OEM: 34560-52

17. Adapter Plate Gasket
 VT No: 15-1037 OEM: 34565-52
 18. Neutral Indicator Switch
 VT No: 32-9065 OEM: 33900-59C
 19. Washer
 VT No: 15-0217 OEM: 25811-11
 20. Cam Follower Retainer
 VT No: 17-0075 OEM: 34064-52
 21. Retainer Washer
 VT No: 17-0916 OEM: 34066-52
 22. Spring
 VT No: 13-0130 OEM: 34068-52A
 23. Cam Follower
 VT No: 17-0076 OEM: 34062-52
 24. Camshaft Lock Screw
 VT No: 17-0132 OEM: 34050-36
 25. Cam Shaft
 VT No: 17-0134 OEM: 34031-41
 26. Oil Seal
 VT No: 14-0117 OEM: 34036-36
 27. Shifter Cam
 VT No: 17-9766 OEM: 34019-73
 28. Cotter Pin
 VT No: 37-8661 OEM: 534
 29. Shifter Gear
 VT No: 17-9782 OEM: 33960-74
 30. Shifter Gear Spring
 VT No: 13-0126 OEM: 33390-26
 31 Shifter Shaft
 VT No: 17-9796 OEM: 34453-52
 32. Shifter Cover
 VT No: 17-0106 OEM: 34803-59

33. Pawl Carrier Bushing
 VT No: 10-0726 OEM: 34498-52
 34. Shifter Shaft Bushing
 VT No: 10-0725 OEM: 34435-52