

**V-Twin Mfg.**  
**Inverted Fork Oil Change**  
**VT Part No. 24-0718**

**This is a custom application and rider safety depends on proper installation. This product should only be installed by a knowledgeable and trained motorcycle technician. V-Twin Mfg. accepts no responsibility for improper installation.**

**Fork Oil Change Instructions:**

1. In order to change fork oil, raise the bike off of the floor and secure it.
2. Remove the front wheel
3. Remove the front fender.
4. Remove the front brake caliper and support it. Do not let it hang by the brake line. Do not squeeze the front brake lever while caliper is in this position.
5. Now loosen pinch bolts in triple tree until forks can be removed.
6. Remove fork legs and turn upside down. Now remove lower caps (where axle goes) from the fork tubes. Be careful as the caps are under spring pressure.
7. Drain oil out and refill with fresh oil 10 oz per leg of type 'E' fork oil.
8. Reinstall the lower fork caps. Use of the leg of tool VT No. 16-0573 will greatly aid in this step. Once lower caps are installed reassemble the fork, wheel, fender and caliper assembly.

