

VT No. 27-1772 Driver Footboard Relocator Kit

Parts included

- 1 Left Front Bracket
- 1 Left Rear Bracket
- 1 Right Front Bracket
- 1 Right Rear Bracket
- 1 Hardware Kit containing 4 shoulder bolts and 4 lock nuts

1. Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.
2. Starting on the left (clutch) side, remove the existing floorboards and hardware. Set floorboard and hardware aside, they will be reused.

Note: Pay attention to how the hardware is installed and how the floorboard is mounted. You will be reinstalling these items in reverse order in a later step.

3. Locate provided Left Front and Rear brackets, two (2) shoulder bolts, and (2) lock nuts.

Note: Take note of the stampings made on the inside of the brackets for assistance on determining sides.

LF = Left Front (clutch side), LR = Left Rear (clutch side) RF = Right Front (brake side), RR = Right Rear (brake side)

4. Align and place the LF Bracket on the front floorboard mount, and the LR Bracket on the rear floorboard mount. Insert provided shoulder bolts, from the front-side of the bike, through the aligned mounting holes.
5. Fasten the brackets to the floorboard mounts using the provided Lock Nuts. Fully tighten hardware.
6. Locate the floorboard and hardware that was removed in Step 2. Install the floorboard to the relocation brackets in the reverse order of which it was removed. Fully tighten hardware.
7. Repeat steps 2 through 6 on the right (brake) side.

Warning: CHECK TO MAKE SURE THAT THERE IS PROPER CLEARANCE WHEN CORNERING. LOSS OF CONTROL OF THE MOTORCYCLE AND SERIOUS INJURY MAY OCCUR WITHOUT PROPER CORNERING CLEARANCE.

Note: CHECK CLEARANCE FOR PROPER OPERATION OF CONTROLS. THE RELOCATOR BRACKETS PROVIDE MORE ROOM TO PLACE YOUR FEET/ NEW RIDING POSITIONS. CONFIRM CLEARANCE AND RELATION OF THE POSITION OF YOUR FEET TO THE SHIFTER AND THE BRAKE PEDALS.

Note: IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. WE WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS