

Seat T-bar and Post Assembly Fits all Softail® models 1984-1999

Seat T-bar Installation Instructions

Front hinge mounts on top of the rear gas tank mounting tabs using the existing frame mounting holes, see photo "A" below.




Photo A

Seat spring assembly mounts on top of the frame seat post tube. For best appearance, align the seat spring assembly with frame seat post tube. Mounting flange points to the rear, see photo "B" below. Using seat spring base mounting holes as a guide, mark and drill frame for self-tapping screws. Use the center adjusting screw to fine-tune the angle of the seat post.




Photo B