

V-Twin Mfg.
Steel Braided Oil Line Set
VT Part No. 40-9996 & 40-9997

Tech Tip

Some of the oil lines in our kits have the nut in front of the bend for the oil line and appear as though they cannot be used.

This problem is easily fixed by following the the below listed steps.

1. Inside the nut there is a bushing. See photo of bushing circled in red.
2. The bushing sits inside the nut and is used to affix the nut at the end of the flare on the tube.
3. If you slide the bushing up first and slide it over the bend, you will then be able to move the nut over the bend on the tube.
4. Then slide the bushing back into the nut.
5. At this point the nut is in the correct position and can be properly installed.

