How to measure springer length.



Measure from bottom of lower triple tree



to center of axle holes