

How to measure springer length.



**Measure from bottom
of lower triple tree**

to center of axle holes

