

UNI FILTER CLEANING INSTRUCTIONS

Uni Filter Oiling Instructions: Remove the filter frame (if applicable) and saturate the foam element with the Uni Foam Liquid or Spray Filter Oil.

GREASE CUTTING CLEANER IS NECESSARY FRO PROPER CLEANING!

Remove the filter frame (if applicable). Next saturate the foam element with cleaner. Uni Foam filter cleaner part #41-0173: spray generous amounts of the cleaner on the inside and outside of the filter.

Let is soak for 3-4 minutes.

Rinse out the filter element in warm water until clean.

A second application may be necessary for heavily soiled elements.

Let filter dry completely.

VERY IMPORTANT: Re-oil per instructions and you are ready!

Products like Simple Green, dish soap or mild solvents can be used if Uni Cleaner is not available. Pour cleaning solution into a bucket, dunk the filter in multiple times until clean.

Rinse with warm water.

Let filter dry completely.

VERY IMPORTANT:Re-oil per instructions and you are ready!

Clean filter frame, clean filter mounting surface and air box.

Now your ready to oil and install air filter!